

# Test Boxes

## Testing and Troubleshooting

For All R.R. Brink Electrical Locks & Sliding Devices



**R.R. BRINK LOCKING SYSTEMS, INC.**  
500 Earl Road • Shorewood, IL 60404  
Tel: 815-744-7000 • Fax: 815-744-7020  
www.rrbrink.com

### B00080-000

#### Application and Features

- For testing **sliding cell** and corridor devices:
  - 57700
  - 57300
- Includes Adapters for:
  - 57300

### B00043-A

#### Application and Features

- For testing all **120v** motor & solenoid locks:
  - 5020M
  - 5020S
  - 7050M
  - 7050S
- Includes Adapter for:
  - 7050M/7050S
- Tests All Functions:
  - MSLH
  - MCLH-M
  - MCLH-E
- Shipped with instructions and troubleshooting guide.

### B00068-A

#### Application and Features

- For testing all **24v** motor & solenoid locks with **Fail Secure**:
  - 3520-300
  - 3520-600
  - 5020M
  - 7050M
  - 3020 FSE
  - 1050 FSE
  - 2020 FSE
- Tests All Functions:
  - MSLH
  - MCLH-M
  - MCLH-E
- Shipped with instructions and troubleshooting guide.

### B00069-A

#### Application and Features

- For testing all **24v** solenoid locks with **Fail Safe**:
  - 3020FS
  - 2020FS
  - 1050FS
- Tests All Functions:
  - MSLH
  - MCLH-E
- Shipped with instructions and troubleshooting guide.